

MAINTAINING YOUR GLASS STAINING

Perth's water is often stated as being 'hard', referring to the concentration levels of magnesium salts and calcium in water. They are natural minerals that dissolve as they move through soil and rock. Water becomes 'harder' as the magnesium salt and calcium content increases. These minerals can often build-up within showers and stain shower glass if not treated - this is referred to as 'calcium build-up', or 'soap-scum'.

Tips for Cleaning Showers:

Tip 1: Showers should be cleaned frequently, however just 60 seconds of cleaning following each shower makes the shower much easier to maintain. The steam from the shower helps to loosen dirt and build-up, making it easier to clean.

Tip 2: A cleaning tool with a square-shaped head allows for the easy removal of stubborn soap scum from shower corners.

Tip 3: Soap scum accumulates on faucets and soap trays as well, so make sure you are effectively cleaning every inch of your shower.

Tip 4: Always use a squeegee or a towel to wipe down the shower walls and doors after use. Hang any shower tools like loofas, sponges or brushes to drip-dry completely and clear the drain of any hair remains.

Recommended Cleaning tools:

- Extendable Scrubber Mop
- Magic Eraser
- Window Squeegee
- Scrubbing Brush

